KENWOOD

3rd IMDR **110**dB* RMDR **122**dB* BDR **150**dB*

For DX Enthusiasts

 $\frac{\text{HF}/\text{50MHz}/\text{70MHz}\text{ Transceiver}}{\text{TS-890S}}$



Performance Exceeding Expectations.





The most rewarding results often take place when faced with the harshest and most challenging conditions. There are enthusiasts who know this all too well because of their love of DX. KENWOOD has the answer. Achieve results through certainty and not circumstance. Delivered through impeccable receiver and audio performance. This is our offering to you.



 $\frac{\text{HF}/50\text{MHz}/70\text{MHz} \text{ TRANSCEIVER}}{\text{TS-890S}}$

<Actual Size> 396(W)×141.3(H)×340(D)mm (not including protrusions)

Top in its class with three dynamic ranges. Alive and well, the non-tiring KENWOOD tone keeps you listening.




Photograph shows optional 270Hz roofing filter installed


Receive performance on a whole other level from narrow bandwidth roofing filters that only full down conversion can provide


The TS-890S uses 8.248MHz 1st IF frequency down conversion for its receive signal system in order to continue the adjacent interference signal exclusion legacy refined in the TS-990S. This means you can use narrow bandwidth crystal filters with passband widths of 500Hz or 270Hz (optional YG-82CN-1) as roofing filters to achieve strong exclusion of unnecessary adjacent signals. The 1st mixer is the H-mode mixer also carried by the TS-990S.

Conversion characteristics have been improved with fine-tuning of input/output matching as well the device used.









Reciprocal mixing dynamic range (RMDR)

Measurement conditions (shared) Frx=14.2 MHz, PRE AMP OFF, BW 500 Hz, CW Vertical axis: Dynamic range (shared)

Horizontal axis: Interference signal interval (3rd IMDR), interference signal isolation frequency (RMDR, BDR)

•Values are measured examples.

Band scope receive **Roofing Filters** 270Hz ATT (Option) 500Hz throug 2.7kHz RF BPF H-mode Post Amp 6kHz PRE AMF Receive signal system 15kHz Down conversion receiver

High-speed scanning with independent band scope receiver


The configuration of the band scope receiver has changed from the superheterodyne system used in the TS-990S to 1st IF sampling using an A/D converter (14bit/39MHz), and FPGA digital down conversion. This means a change in scanning method from step FFT to FFT, achieving highspeed updates to the display irrespective of span settings.





Local oscillator realises superior C/N

Interference signal exclusion is not determined by roofing filters and signal system devices alone. The TS-890S has taken the VCO division of the TS-990S and developed it further, combining a VCO device with high C/N in the gigahertz band and a reference oscillation circuit with superior adjacent C/N to deliver C/N characteristics unattainable in conventional units.




1st Local OSC Phase Noise (14.1MHz) •Values are measured examples.

The speed and quality of KENWOOD's renowned IF AGC control

A variety of functions are realised through 32-bit floating-point DSP technology inherited from the TS-990S, including modulation/demodulation in all modes, IF filter, IF-AGC, and removal of interfering signals. Popular for its non-tiring and great-quality audio, the IF-AGC has undergone a facelift with a combination of roofing filters and IF filters, and has been designed to enable optimal control under various noise circumstances.



For IF DSP, transmitter ADSP-21363 clock @332MHz



32MHz ADSP-21363 clock @332MHz

Other receiver system features

●RF ATT(OFF/6/12/18dB) ●Preamp(PRE1/PRE2) ●Receive only antenna connector(RX IN, RX OUT) ●Antenna output connector

Diverse interference / noise removal features

IF filter

Passband frequency range expansion through LOW-CUT/HI-CUT, WIDTH/SHIFT. Interfering signal removal and desired audio-quality adjustment, as well as more convenient operation in digital mode. Operation with LOW-CUT / HI-CUT in SSB/AM/FM mode, WIDTH/ SHIFT in CW mode, and WIDTH function in FSK/PSK mode. Change to WIDTH/SHIFT operation as in CW mode also possible in SSB/SSB-DATA mode. Selection of roofing filter (270Hz*/500Hz/2.7kHz/6kHz/1 5kHz) can be automatic to match IF filter passband width or manual to selectable frequencies.

(*270Hz when option mounted)

IF filter shape, AF filter

Switching is possible between 3 kinds of IF filter shapes: Medium/ Soft/Sharp. Switching is also possible for post-demodulation voiceaudio between 3 kinds of AF filter passbands: Medium/Wide/ Narrow. Combinations of these settings can adjust the sharpness of the demodulation signal.

Audio peak filter

This is a narrow bandwidth peak filter operated during receive in CW mode. When intelligibility is low due to noise, it has the effect of floating the target signal and increasing intelligibility. The central frequency is linked to the pitch frequency, and can be given a maximum peak gain of +6dB.

Notch filter

A notch filter that operates in the IF stage. By eliminating strong interfering signals, it allows weak target signals to stand out. Damping range can be switched between three levels: Narrow/Middle/Wide, enabling operation to match interference conditions.

Noise reduction function (NR1/NR2)

In addition to conventional NR1/NR2 noise reduction, NR1 comes equipped with noise reduction using spectral-subtraction, which focusses on noise reduction in voice-audio system modes. The optimum noise reduction method is applied for each receive mode.

Noise blanker

A noise blanker reduces crackling, pulse-type noise. The TS-890S includes two kinds of noise blankers: NB1, which processes analogue signals, and NB2, which carries out digital processing in the IF stage using DSP. Furthermore, selection of NB2 can be made from two kinds of NB with different operating principles. Either NB1 or NB2 can be used depending on noise conditions, or both can be used simultaneously.

Beat cancel function (BC1/BC2)

While a notch filter (IF stage) is effective for a single strong beat, beat cancelling (AF stage) shows results on multiple, comparatively weak beats. BC1 is effective on weak beats and continuous beats, while BC2 is effective on intermittent beats like CW signals.

AGC Quick recovery

A function to recover from suppression that happens when pulse noise is included in a receive signal.

Evolved power to perform with diverse displays and auto-scroll. A transmitter with stable output, quietness and high speed.

Display / Transmitter The unit carries a high definition 7-inch TFT color display. KENWOOD In addition to a diverse range of display content, the convenient AUTO SCROLL MODE provides 0 000 strong support for competition or similar operation. RKER Other strengths include clean and stable 7.005.000 🐁 7.007.000 100W^{*} transmitter output, improved quietness from twin cooling fans, and high-speed operation enabled by an auto antenna tuner. Display/Transmit *70 MHz band is 50 W

Operational capacity reinforced with displays and various features



The seven-inch TFT color LCD is the same size as that used in the TS-990S. In addition to basic information including frequency, mode, and S-meter, the band scope and audio scope are also displayed. The TS-890S also displays further improvements in visibility and operability in tough usage scenarios such as competitions.

With the spectrum scope and waterfall screen display, the analogue meter is simultaneously displayed. The popular sub-scope display from the TS-990S has been incorporated as a filter-scope display

A band scope providing ease-of-ease

AUTO SCROLL MODE


In addition to conventional CENTER MODE and FIXED MODE, the unit comes equipped with an AUTO SCROLL MODE. While in FIXED MODE, if the receive frequency goes over the scope edge, then autoscroll will engage for half a screen width. Furthermore, with the EXPAND function turned on, the screen to be displayed next can be drawn in advance*. Also, with the SHIFT function, the receive marker can be set in the desired position on the vertical grid, which is convenient when displaying a non-receive frequency as the center display, such as for pileups during splits. *: Effective in spans under 200kHz. Image becomes slightly coarse when expanded.



Auto-scroll operation (span 10 kHz, EXPAND ON) On the current screen (screen 2), if the frequency is changed to go over the top end of screen 2, it will automatically change to screen 3, and if it goes over the bottom end of screen 2, it will automatically change to screen 1. Waterfall screen creation normally commences after switching screens, but with the EXPAND function turned to ON, the display switches to the finished screen.

CENTER MODE

When changing the receive frequency in CENTER MODE, there are many units that display a bright line that flows obliquely over the waterfall, but with the TS-890S, the bright line remains straight and enables tuning operation*. Switching to the follow display is also possible via the menu. *: During straight display, the waterfall bright line temporarily stops and undergoes parallel displacement. Image becomes slightly coarse when expanded.



FIXED MODE

FIXED MODE allows you to switch between three kinds of display ranges with a single touch of the panel screen. The initial value is preset based on the band plan, but this can be easily adjusted to a desired scope.

Improved reference level operability ease-of-use

The TS-890S has improved operability of the reference level focusing on the visibility of the waterfall. •Through optimisation of each span, readjustment is mostly unnecessary when switching between them.* •Settings are enabled for each band, and readjustment is also unnecessary for the PRE AMP ON and PRE AMP OFF bands.


*: Spectrum scope waveform height changes during span switching

Receiver • LCD Display/ Transmit • Control • Specifications •



Filter scope display

The popular sub-scope from the TS-990S is carried as a filter scope display. You can confirm receive filter selection status, roofing filter bandwidth, IF filter passband information, receive for ex-audio spectrum, CW pitch frequency, and notch frequency all concentrated in one location.



SSB mode display example

Expanded touch operation scope

Basic operation of the TS-890S is through knobs and switches with a definite 'clicking' feel rather than touchscreen operation, but the below adjustment features and menu settings can now be changed via touch operation.

RX/TX equaliser level adjustment, meter type (analogue white / analogue black / bar meter) switching, FFT scope/X-Y scope switching on RTTY decode screen, FFT scope/ vector scope switching on PSK decode screen, voice-audio file playback position change. Furthermore, with touchscreen tuning, in addition to the conventional CW tuning operation via long-push, a short push enables tuning using steps set via MULTI/CH, while on bands popular with operation in units of 1kHz, practical touch alignment is possible even in SSB.

Other display system features


•Transmit digital meter enabling display of two kinds of transmit information even during analogue meter display •Audio scope (spectrum scope, oscilloscope) able to be displayed simultaneously with reduced band scope •Band scope IF filter passband with display •Change of gradation for waterfall display •Frequency marker display function (Max. 50) •Transmit spectrum display (during CENTER MODE) •SWL display mode.

Heavy-duty design delivers transmission performance able to withstand long hours of operation.

Highly reliable 100W final-stage amplifier circuit. (*70 MHz band is 50 W)

The final-stage amplifier device is a Mitsubishi-made MOSFET RD100HHF1(Pch 176.5W) operating in push-pull. A MOSFET RD16HHF1 has been used for the drive amp, and a MOSFET RD06HHF1 for the pre-drive amp. Inter-stage matching and fine-tuning delivers superior transmit IMD even for a 13.8V final circuit, enabling operation with a clean and low-distortion signal.






14MHz transmit IMD example (100W output) •Values are measured examples.

Heavy-duty design with improved quietness

The unit employs a twin cooling fan system that uses a pair of 80 x 80 mm fans. Using two fans provides sufficient air flow at low rpm, making for superior quietness. The quietness level for the fans when operating has been improved by more than 5dB compared to our conventional models. Furthermore, the use of an aluminum die-cast chassis combined with a large heat sink makes for a heavy-duty design sufficiently capable of withstanding the tough conditions typical of contests or long hours of hard operation.





The position of the heatsink in the center of the rear panel

Built-in high-speed automatic antenna tuner enabling high-speed operation



The antenna tuner is a preset type also operable during receive and covering amateur bands from 1.8MHz~70MHz. High-speed operation and the proven relay method enable rapid QSY through instantaneous band changing. The menu can be used to set an ON/ OFF memory for the antenna tuner for each band.


Free settings enabled through linear amp control settings menu

A variety of linear amp connections have been taken into account, including self-made ones, and independent settings for various kinds of control at HF/50MHz, 70MHz bands are possible. Possible settings include: linear amp ON/OFF, transmission control (H active, L active), transmission delay ON/OFF, transmission delay time (CW/FSK/PSK) and (SSB/AM/FM), internal relay control, and external ALC threshold voltage adjustment.

TCXO as standard, high frequency stability at ±0.1 ppm

Equipped with a TCXO (temperature compensated crystal oscillator) requiring no warm-up as standard, high stability of ± 0.1 ppm has been obtained in a wide temperature range covering from 0°C~+50°C. External standard signal (10MHz) input is also possible.





•Values are measured examples.

Other transmit system features • USB keying/SEND • DRV connector output (supports transmission in 137kHz and 475kHz bands) • Transmit output limiter (supports ON/OFF switching, mode settings) • TX tuning

Delivering the ultimate in split-operation operability. An interface that thinks of everything.



Stronger split-operation handling through VFOA/B

Split frequency settings

In addition to conventional split frequency setting methods, the TS-990S's proven split setting functions have been included. For 2kHz UP, press '2' on the number pad after a long press of the SPLIT key and the settings are complete. Split frequencies can be set within the range of \pm 9kHz (1kHz steps).

RX ANT	DRV	GENE		
1.8	3.5	7		
10	14	18		
21	24	28		
CLR	50	ENT		
RECORDER				

Band direct key

Band changing possible while keeping split settings for each band (menu setting feature)

In the split state, changing the band or band memory via the band direct key will make changes while keeping the split state. Individual settings are possible for the split frequencies and modes for each band memory, which is convenient for chasing DX-peditions during multiband/mode operation.




Split frequency changing (menu setting feature)

In addition to the conventional method of operating the tuning knob during TF-SET, when RIT/XIT is not in use, the split frequency can also be changed by operating the RIT/XIT knob.



Split frequency receive via external receiver (menu setting feature)

By connecting another TS-890S or TS-590S/SG^{*1} unit to the ANT OUT connector to use as a sub- receiver^{*2} and using the split transfer function A, this can enable assistance in 2-wave simultaneous receive during split operation ^{*3}.



IF filter A / B/C one-touch switching

Three kinds of bandwidth presets and instantaneous switching are possible for IF filters. Switching can also be limited to 2 kinds, so this enables use for wide/ narrow switching. Using the FIL.CLR key, a changed bandwidth can be returned to a preset frequency with a single touch.



*1: Requires a firmware update. *2: Loss of approximately 3dB (theoretical value) is experienced *3: Frequency transfer, standby, and sub- receiver audio mute are possible. Requires separate antenna cable and RS-232C cross-cable. Not compatible with combined SP/headphone use.





CW Morse code decode/ encode possible with stand-alone unit

The unit is compatible with CW Morse code decode/encode. Transmission of Morse code is possible with text input from a USB keyboard. Combined use of templates sent from message memories and Morse code transmissions via panel is also possible. Dedicated decode filter switching, and functions for transmission logs and output of decoded text to PC are also included.

	2.016	1014	7.612	7.010	1:00	7.006			
	1MS	1940		CH Encosil		DECODE			
MAX-Po			CO DX CO			CO DX CO DX DE JA1YK			
OFF		DI Nist	SE K	OX DE JA1YKX JA1YKX P					
METER Po	JA1200	1 CO CO DE							
	DX DE	2 CQ DX CQ							
		3 0R27							
	¢	4 UR SNN BK							
APE									
ON									

CW decode/encode screen

FSK/PSK functions

• RTTY basic operation settings (keying polarity, shift width, HI/LO tones, reverse mode)
Compatible with PSK31 (QPSK, BPSK) and PSK63 (BPSK) • RTTY/PSK operation via on-board decoder/encoder (USB keyboard compliant) • Message memory function • Tuning scope display (audio FFT, waterfall/X-Y scope (FSK)/vector scope (PSK))

Compatible with FM operation on 28MHz, 50MHz, and 70MHz bands


The unit includes switching to FM narrow for transmit and receive, as well as repeater operation support and FM signaling functionality (CTCSS, cross-tone).

DATA mode compatible with external input/output switching

Separate from the microphone connector, the back panel includes a variety of I/O interfaces, including analogue audio input and output, USB audio interface, and LAN(VoIP)interface. By combining DATA mode with SSB/FM/AM modes, it is possible to freely set channels for modulation and demodulation. Furthermore, combined use with DATA VOX enables the transmission of modulation signals from a PC, rendering standby wiring and commands unnecessary.

Remote operation achieved without host PC Direct remote-control function (KNS)

When operating using the KNS (KENWOOD Network Command System), remote operation of the radio as possible by a direct LAN connection. Conventional connection using a host PC and ARHP (Amateur Radio Host Program) is also possible.



USB memory/USB cable firmware update function

Starting the unit in update mode and inserting a USB memory stick containing firmware into the front USB-A port will start an automatic update. Updates can also be carried out by connecting the TS-890S to a PC via a USB cable, and moving a firmware file using drag & drop on top of the 'TS-890S' removable device that is displayed on the PC's desktop during update mode.

Recording functions

The TS-890S comes equipped with a 1GB internal memory, and can record a maximum of roughly 9 hours of audio without using USB memory*. When using USB memory, depending on the capacity, there are no limits on the amount of audio recording. Recording options include normal, constant, and timer, and recording can also be linked to the squelch.

*: Other files sharing memory capacity may result in less than 9 hours.

Diverse functions supporting CW operation

- PADDLE/KEY jack (one each on front/rear, compatible with paddle/ straight key switching)
- CW auto tuning
- Full break-in and semi breakin (semi break-in delay time: 50ms~1000ms)
- CW Pitch control, Side tone (pitch frequency linking 5Hz steps)

Other operation functions, main connectors

- 120 channel memory
- XIT shift enabling one-touch transition to split mode from XIT operation
- Main knob fast-forward
- CONFIG A/B function enabling overall switching of menu and all settings depending on operation environment.
- Voice guidance function
- ID beep function notifying callsign transmission guide

- settings, keyer mode A/B selection) • 8CH CW message memory function
 - Auto-switch to CW mode on keydown in SSB mode

• Built-in electronic keyer (key speed

- Microphone paddle mode
- CW auto wait/wait reverse • CW reverse mode / CW BFO side
- band switching
- 3 PF keys • Screen capture
 - User screen slideshow screensaver
 - LAN connector
 - USB-A connector (1 each on front/ rear) CW auto wait/wait reverse
 - USB-B connector
 - External display connector (DVI-I)
 - KEYPAD jack (add up to 8 external PF kevs)
 - External analogue meter output
 - Packet cluster tuning

KENWOOD SKY COMMAND® II support

(When connected to TH-D72E/TM-D710E*/TM-D710GE)**

Enables full-duplex operation with improved functionality such as visual confirmation of HF frequency on the LCD panel. Control via TNC (AX.25) enables more accesses to HF functions: XIT, mode switching, split-frequency operations on/off, memory shift, and frequency step selection. The transporter sends out its pre-programmed call sign via CW every 10 minutes.



*Discontinued produc

KENWOOD SKY COMMAND[®] II uses a pair of TH-D72E or TM-D710E*/ TM-D710GE transceivers Note: Refer to applicable Amateur Radio regulations to check whether you are permitted to use this function.



Main Options



Receiver • LCD Display/ Transmit • Control • Specifications •





TS-890S Specifications

General			
	160m band	1.81 ~ 2.0 MHz	
	80m band	3.5 ~ 3.8 MHz	
	60m band *1	5.25 ~ 5.45 MHz	
	40m band	7.0 ~ 7.2 MHz	
	30m band	10.1 ~ 10.15 MHz	
Frequency	20m band	14.0 ~ 14.35 MHz	
range (Transmitter)	17m band	18.068 ~ 18.168 MHz	
	15m band	21.0 ~ 21.45 MHz	
	12m band	24.89 ~ 24.99 MHz	
	10m band	28.0 ~ 29.7 MHz	
	6m band	50.0 ~ 52.0 MHz	
	4m band	70.0 ~ 70.5 MHz	
Frequency range (Receiver)		0.13 ~ 30 MHz, 50 ~ 54 MHz, 70.0 ~ 70.5MHz VFO: Continuous 30 kHz ~ 74.8 MHz	
Mode		A1A(CW), A3E(AM), J3E(SSB), F1B(FSK), F3E(FM), G1B(PSK)	
Frequency stability		±0.1 ppm, 0 °C ~ +50 °C	
Antenna impedance		50 Ω	
Antenna tuner lo	oad range	16.7 Ω ~ 150 Ω	
Supply voltage		DC 13.8 V ±15 %	
Ground		Negative ground	
	TX	22.5 A or less	
Current Drain	RX (No signal)	2.5 A or less	
Operating Temp	erature	$0 ^{\circ}\text{C} \sim +50 ^{\circ}\text{C}$	
	Without projections	W396.0 × H141.3 × D340.0 mm	
Dimensions	With projections	W409.6 × H158.3 × D387.4 mm	
Weight	1	Approx. 15.8 kg	
Transmitte	er		
		HF/50MHz: Max 100 W / Min 5 W, (Max 25 W / Min 5 W)	
Output Power ((AIVI)	70MHz: Max 50 W / Min 5 W, (Max 12.5 W / Min 5 W)	
Modulation		SSB: Balanced, AM: Low Power, FM: Reactance	
Maximum freque	ency deviation (FM)	wide: ± 5 kHz or less, narrow: ± 2.5 kHz or less	
		HF: -50 dB or less	
Spurious emissions		50 MHz: -63 dB or less	
		70 MHz: -60 dB or less	
Carrier suppression		60 dB or more	
Unwanted sideband suppression		60 dB or more	
Transmit frequency response		Within -6 dB (100 ~ 2,900 Hz)	
Microphone impedance		600 Ω	
XIT variable range		±9.999 kHz	

Receiver				
Circuit type		Double Superheterodyne		
Intermediate	1st IF	8.248 MHz		
frequency	2nd IF	24 kHz / 36kHz (FM)		
		0.5 µV (0.13 ~ 0.522 MHz)		
	SSB / CW / FSK / PSK (S/N 10 dB)	4 μV (0.522 ~ 1.705 MHz)		
		0.2 µV (1.705 ~ 24.5 MHz)		
		0.13 μV (24.5 ~ 30 MHz)		
		0.13 μV (50 ~ 54 MHz)		
		0.13 μV (70 ~ 70.5 MHz)		
		6.3 μV (0.13 ~ 0.522 MHz)		
Sensitivity (TYP)		31.6 µV (0.522 ~ 1.705 MHz)		
(111)		2 µV (1.705 ~ 24.5 MHz)		
	AM (S/N 10 dB)	1.3 μV (24.5 ~ 30 MHz)		
		1.3 μV (50 ~ 54 MHz)		
		1.3 μV (70 ~ 70.5 MHz)		
		0.22 μV (28 ~ 30 MHz)		
	FM (12 dB SINAD)	0.22 μV or less (50 ~ 54 MHz)		
		0.22 µV or less (70 ~ 70.5 MHz)		
		5.6 µV or less (0.13 ~ 0.522 MHz)		
	SSB / CW / FSK / AM	18 µV or less (0.522 ~ 1.705 MHz)		
		1.8 μV or less (1.705 ~ 30 MHz)		
Squelch		1.1 μV or less (50 ~ 54 MHz)		
Sensitivity		1.1 μV or less (70 ~ 70.5 MHz)		
	FM	0.2 μV or less (28 ~ 30 MHz)		
		0.2 µV or less (50 ~ 54 MHz)		
		0.2 μV or less (70 ~ 70.5 MHz)		
Image Rejection Ratio		HF:70 dB or more, 50 /70 MHz: 60 dB or more		
IF Rejection Rati	io	70 dB or more		
	SSB	2.6 kHz or more (-6 dB)		
		4.4 kHz or less (-60 dB)		
	CW / FSK	500 Hz or more (-6 dB)		
		1.2 kHz or less (-60 dB)		
Selectivity	АМ	6.0 kHz or more (-6 dB)		
		12 kHz or less (-50 dB)		
	FM	12 kHz or more (-6 dB)		
		25 kHz or less (-50 dB)		
RIT variable range		±9.999 kHz		
Notch filter attenuation		60 dB or more (Auto), 70 dB or more (Manual)		
Beat cancel atte	enuation	40 dB or more		
Audio output		1.5 W or more (8 Ω)		
Audio output impedance		4 Ω ~ 8 Ω		

Dimensions







*1 60 m band: Refer to applicable Amateur Radio regulations to your country.

DC power cord x1 7 pin DIN Plug (For REMOTE connector x1) 13pin DIN Plug (For ACC2 connector x1) Spare Fuse 4A x1

Supplied accessories

Electronic specifications apply only to amateur bands. Receive sensitivity drops in the vicinity of the 1st IF frequency (8.248MHz) due to IF trapping. Internal beat may occur during amateur band receive. Band scope (waterfall) screen may also display spurious signals other than receive signal.

Spare Fuse 25A x1
 Operation Manual x1

Warranty Card x1

KENWOOD SKY COMMAND SYSTEM II is a registered trademark of JVCKENWOOD Corporation in the U.S. JVCKENWOOD follows a policy of continuous advancement in development. For this reason, specifications may be changed without notice. *Alterations may be made without notice to improve the ratings or the design of the transceiver. *The photographic and printing processes may cause the coloration of the transceiver to appear different from that of the actual transceiver.

JVCKENWOOD U.K. Limited

12 Priestley Way, London, NW2 7BA, United Kingdom

https://kenwoodcommunications.co.uk/

